




GENUINE PARTS

INSTALLATION INSTRUCTIONS

1. DESCRIPTION:	Fog Lamp Kit
2. APPLICATION:	Versa Note (SV Only)
3. PART NUMBER:	999L1 4Z000 - Fog Lamp Kit

4. KIT CONTENTS:			
Item	QTY	Description	Service Part Number
A	1	Combination Switch	25560 3VA0A
B	1	Fog Lamp Assembly (RH)	26150 8992A
C	1	Fog Lamp Assembly (LH)	26155 8992A
D	1	Bracket ASSY (RH)	26910 3VY0A
E	1	Bracket ASSY (LH)	26915 3VY0A
F	1	Sub Harness	B61E1-JJ000
G	7	Cable Tie w/ Mounting Clip	24225-C9901
H	6	SCR-TAP,HEX HD FLG TYP	85-66620-5A
I	4	Clip, FR BMPR	62228 5Z000



5. TOOLS REQUIRED
<ul style="list-style-type: none"> • Trim stick/Pry tool • #2 Philips screwdriver • Protective cloth • T-20 Torx Driver • Short, 1/4" ratchet drive with 10mm Socket • Utility Knife • Flush-cut Clippers



6. PRE-INSTALLATION CAUTION/NOTES
<ul style="list-style-type: none"> • Dealer installation recommended. Instructions may refer to Service Manual • Installation may require special tools • This part is to be installed at a surface temperature no warmer than 65-100°F • Remove and prepare templates located at the end of Installation Instructions

CAUTION

- This accessory must only be installed as specified in these instructions.
- Ensure at all times that parts are securely fitted and will not compromise the safe function of vehicle systems.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit

7. INSTALLATION OVERVIEW



8. CRITICAL STEPS

The following steps are critical and must be performed **EXACTLY** as specified to ensure proper installation:

- Location of the lights must be followed exactly as described in this instruction.
- Be sure to apply masking tape as needed in order to protect any areas that may become scratched or damaged by tools.
- Be sure to apply foam tape to any wiring components that can be damaged over time by sharp edges.
- Test the functionality of the kit before final clean up and reinstallation of interior panels.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit


9. VEHICLE PREPARATION:

- 1) Apply parking brake
- 2) Confirm the vehicle is no longer in the default shipping state (Extended Storage Switch Pulled Up and BCM in Transit Mode). Failure to confirm the vehicle has been removed from this state will result in the loss of normal vehicle operation.

3a) Locate the Extended Storage Switch in the cabin fuse block. Once located, check that it is in the "Customer" position. See below for reference.


3b) To remove transit mode:

1. Remove fuse cover lid
2. Push down shorting pin
3. Ign On 2 times without turning vehicle on



To return to transit mode:

1. Ign Off
2. Remove fuse cover lid
3. Pull up shorting pin
4. Assemble fuse cover lid
5. Ign On 2 times without turning vehicle on
6. Confirm transit mode condition on meter



NOTE: Typical vehicle condition shown here. Switch is easily identifiable by the permanent, push-pull fuse holder. Actual position on the fuse block may vary, vehicle to vehicle.


4) Record customer radio presets.

	1	2	3	4	5
A					
B					
C					

NOTE: USE CAUTION WHEN REMOVING / RE-INSTALLING TRIM COMPONENTS TO AVOID DAMAGE, SCRATCHES, BREAKING OF CLIPS AND / OR INTERIOR TRIM PANELS. MOVE ALL TRIM COMPONENTS TO A PROTECTED AREA.

⚠ WARNING

Disconnect negative battery terminal before proceeding.




10. ORDER OF INSTALLATION


1. Remove panels and trim.
2. Install Fog Lamp Assemblies
3. Route Wiring
4. Replace all panels

INSTALLATION INSTRUCTIONS - Fog Lamp Kit

11. INSTALLATION




1. To prevent scratches to the fascia and/or headlight, apply protective tape around the front fascia as shown.



2. Remove all securing clips from the front cover over the radiator. Release the lower fittings by pulling up vertically. Remove the front cover from the vehicle.

Note: Be sure to store all clips in a safe location for later reinstallation. Use caution to prevent any damage to the clips.




3. Insert a flat-head screwdriver into the left and right service holes in the front grill and rotate to release the torsion clips. Carefully pry off the fitting tabs along the bottom edge of the grill as shown. Pull the grill horizontally out away from the vehicle and set aside.


Note: When reinstalling the grill, place the torsion clips back into position on the back of the grill before fitting the grill into the vehicle.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit

11. INSTALLATION




4. Locate the pre-wire connector for the fog lamps and remove tape holding it to the main harness branch.
5. Connect the sub-harness (B) to pre-wire connector.



6. Route sub-harness (B) through the upper part of the LH side of the engine compartment front side member, and pull it out of the bottom reinforcement along the back side of the existing vehicle harness.
7. Route sub-harness (B) to the RH side along the existing vehicle harness. Pull it out through the bottom of the front RH side member.


Note: Additional routing of the LH side of the sub-harness (B) is required. See Pg. 8.



8. Gather any excess length on the sub harness (B) side, and route it along with the pre-wire connector on the vehicle harness (A). Use a cable tie to secure.
9. Outside of the front side member, use a cable tie to secure sub harness (B) to the vehicle harness (A) as shown.


INSTALLATION INSTRUCTIONS - Fog Lamp Kit

11. INSTALLATION




10. Use cable ties to secure Sub-harness (B) to the holes located in front side member as shown

Note: Make sure there is no slack in sub-harness (B) before securing with cable ties.




11. Secure sub-harness (B) to the hole in the RH front side member bracket as shown. Route the sub-harness (B) under the front side member.

Note: If vehicle bracket is not present due to vehicle specifications, use best judgement to locate a location for the cable tie.




12. Secure sub-harness (B) to the underside of RH front side member bracket with a cable tie as shown.



13. Secure sub-harness (B) on the outside of the front side member (RH). Secure sub-harness (B) to washer tank harness with cable tie as shown.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit


11. INSTALLATION



14. RAISE VEHICLE ON HOIST


15. Begin on **driver** side of vehicle. Locate the lower cover panel under the front fascia in front of the wheel well. Remove three (3) T-20 Torx screws. Remove two (2) press clips as shown. Set all fasteners aside for later reinstallation.

NOTE: Rotate the tire outward to gain access to the wheel well.



16. From the front edge inside the wheel well, remove one (1) T-20 Torx screw and pull the rubber spoiler edging out away from the fascia. Remove three (3) press clips from the inner wall of the wheel well as shown.

NOTE: Rubber chin spoiler may not be present on all vehicles.




17. Pull back the wheel well panel and remove one (1) press clip from the inner cover panel. Carefully pry open both panels to access the inside of the fascia. Set all fasteners aside for later reinstallation.


NOTE: Panels do not need to be removed from the vehicle.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit


11. INSTALLATION



18. Remove the two clips from the fender trim panel.




19. Spread trim panels apart far enough to pull connector through.




20. Keeping trim panels spread apart, carefully pull the sub-harness through (LH) until all slack is removed. Reinstall the two (2) trim panel clips.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit


11. INSTALLATION



21. The factory finisher panel is held in place by six (6) plastic tabs.




22. From **inside** the fascia, use a pair of clippers or other flush-cutting tool to carefully cut away the six (6) plastic tabs holding the fog lamp finisher panel in the fascia from the rear. Remove the finisher panel.




23. Be sure to cut away all excess plastic from the opening.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit


11. INSTALLATION



24. Install two (2) Spring Clips into the mounting bracket as shown. Using the self-tapping hex screws, pre-thread the two mounting holes on each side of the mounting bracket. Remove the screws before installing the bracket.




25. Reach up inside the fascia and snap the mounting bracket into position so the spring clips are fully seated. Locate the pre-wire harness connector inside the fascia. Carefully cut the tape holding the connector and pull it down.




26. From outside the fascia, install one (1) 10mm self-tapping screw at the top inside edge of the mounting bracket as shown.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit


11. INSTALLATION



27. Install the driver side fog lamp assembly into the mounting bracket and secure with two (2) 10mm self-tapping hex screws.




28. Plug the fog lamp harness into the connector at the back of the fog lamp.



29. Carefully press the inner cover panel back into position. **Reinstall** one (1) press clip.


INSTALLATION INSTRUCTIONS - Fog Lamp Kit

11. INSTALLATION




30. Carefully press the lower cover panel back into position. **Reinstall** three (3) press clips. Place the rubber spoiler edging back into position and **reinstall** one (1) T-20 Torx screw.

Note: Rubber chin spoiler may not be present on all vehicles.



31. When resinstalling the rubber spoiler skirt edging, be sure to align it properly with the inside edge of the wheel well.



32. Reinstall three (3) T-20 Torx screws and two (2) press clips as shown under the fascia.


Note: The larger of the two press clips goes in the rear most hole position.

33. Repeat steps 17-34 for the Passenger side of the vehicle.

Note: The extra trim panel inside the Driver side of the fascia will not be present on the passenger side


INSTALLATION INSTRUCTIONS - Fog Lamp Kit

11. INSTALLATION




SWITCH INSTALLATION

34. Turn key to ACC position to unlock steering wheel. Rotate the steering wheel counter clockwise to access the left steering column cover screw. Remove one (1) phillips head screw.




35. Rotate the steering wheel clockwise to access the right steering column cover screw. Remove one (1) phillips head screw.




36. Carefully pry the upper steering finisher off the steering column.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit


11. INSTALLATION



37. With the steering wheel turned to the right, use a phillips head screwdriver to remove one (1) combination switch mounting screw.




38. Rotate the steering wheel counter clockwise and remove one (1) combination switch mounting screw on the left.



39. Locate the combination switch connector plug on the underside of the steering column and disconnect.


INSTALLATION INSTRUCTIONS - Fog Lamp Kit

11. INSTALLATION




40. Remove the combination switch by lifting up and out of steering column.

Discard the combination switch assembly.



41. **Install** the new combination switch supplied with the kit using the original mounting screws.



42. **Reconnect** the wiring plug to the new combination switch.

43. **Reinstall** the upper steering finisher (see Fig. 38).

Note: Steering column cover upper and lower finisher gap spec is 0 +0.5 / -0mm

44. **Reconnect** the negative battery cable.

Note: Be sure to check all wiring. Make sure all trim is in place.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit

12. CHECK OUT

Inspect the vehicle for unfinished work.

- 1) Turn ignition switch ON.
- 2) Turn headlamp and fog lamp switches ON.
- 3) Verify headlamps and fog lamps are illuminated.
- 4) Turn headlamp switch OFF (leaving fog lamp switch ON).
- 5) Verify both headlamp and fog lamps turn off.
- 6) Verify turn signal, wiper, washer and high beam functionality.

NOTE: If this vehicle will be returned to a dealer lot or showroom for an extended period of time, be sure the extended storage switch is placed in the "inventory" position. Refer to the Extended Storage Switch verbiage at the beginning of the 'INSTALLATION PROCEDURE' section.

INSTALLATION INSTRUCTIONS - Fog Lamp Kit

13. BILL OF MATERIALS

Fog Light Kit - 999L1 4Z000

	Parts Contained in Bag Labelled 'Installation Kit'.	Qty	Part Number
1	Combination Switch	1	25560 3VA0A
2	Fog Lamp Assembly (RH)	1	26150 8992A
3	Fog Lamp Assembly (LH)	1	26155 8992A
4	Bracket ASSY (RH)	1	26910 3VY0A
5	Bracket ASSY (LH)	1	26915 3VY0A
6	Sub Harness	1	B61E1-JJ000
7	Cable Tie w/Mounting Clip	7	24225-C9901
8	Screw-Tap, Hex Flg Type	6	85-66620-5A
9	Clip, Frt Bmpr	4	62228 5Z000
10	I/I Replacement Template	1	999V2 AW000
11	INSTALLATION INSTRUCTIONS (WEB)	N/A	999L1 4Z000II

INSTALLATION INSTRUCTIONS - Fog Lamp Kit

14. MECHANIZATION

